


**LABQUEST**  
BY **BOROSIL®**

## ON DEMAND DOUBLE DISTILLATION UNIT

### OPERATING MANUAL

**DDU150**  
**DDU250**  
**DDU400**



**DEALER :**



## THANK YOU NOTE

*We Borosil, one of India's most customer oriented brands truly appreciate your business and express our gratitude for the trust you have placed on us.*

*We hope your choice serves you well in your scientific endeavors and aspire to have the pleasure of doing business with you for years to come.*



**TABLE OF CONTENTS**

<b>Sr.No.</b>	<b>Particular</b>	<b>Page No.</b>
1.	Packing list	7
2.	Product Specifications	9
3.	Safety and Warning	10
4.	Unboxing of the product	12
5.	Product Identification	13
6.	Product Installation	15
7.	Description of Display	20
8.	Process / Working of DDU	21
9.	Settings of DDU	24
10.	Troubleshooting	32
11.	Warranty Registration	35
12.	Statement of warranty	37
13.	Contact Information	38



## PACKING LIST

SR. No.	ACCESSORIES BOX 1	QTY (Nos)
1	DDU unit	1 No.
2	Self Tap Screw N6	4 Nos.
3	Flunged Phillips SS M4x12 Len	8 Nos.
4	Cable Tie 100mm	8 Nos.
5	Hose Clip SS-3/8''(02 with unit & 02 with accessories)	4 Nos.
6	Temperature Probe	2 Nos.
7	Silicon Tube ID 8mmx12mm	8 Mtr
8	PVC Pipe for Boiler Drain(3/4X3/32) DDU400	8 Mtr
9	Silicon tube ID 10mmx14mm	3 mtr
10	Boiler SS Clamp	4 Nos.
11	Braided hose pipe(4mtr With Raw water Inlet1 +4mtr with Raw Water Inlet2)	8 mtr
12	Primary Boiler Base Clamp	2 Nos.
13	Secondary Boiler Base Clamp With Unit	2 Nos.
14	Self Tap Screw N6 - Primary Boiler Bracket	4 Nos.
15	Lateral cock	1 No.
16	Cooling Water Inlet Tubing Sticker	3 Nos.
17	Cooling Water outlet Tubing Sticker	2 Nos.
18	Silica Gel 5gm	2 Nos.
19	Warranty Certificate	1 No.
20	Service Report	1 No.

<b>SR. No.</b>	<b>PRIMARY ACCESSORIES BOX 2</b>	<b>QTY (Nos)</b>
1	Boiler	1 No.
2	Condenser	1 No.
3	Heater	1 No.
4	Probe glass tube	1 No.
5	GL Connectors	4 Nos.

<b>SR. No.</b>	<b>SECONDARY ACCESSORIES BOX 3</b>	<b>QTY (Nos)</b>
1	Boiler	1 No.
2	Condenser	1 No.
3	Heater	1 No.
4	Probe glass tube	1 No.
5	GL Connectors	4 Nos.

## PRODUCT SPECIFICATION

PARAMETERS	DDU150	DDU250	DDU400
Dist. water output cap (Ltr/hr)	1.5 LPH	2.5 LPH	4 LPH
Minimum cooling water requirement (Ltr/min)	1	1.5	2
Total Power consumed (kw)	3	5.5	7
Conductivity (S/cm)	$<1 \times 10^{0-6}$	$<1 \times 10^{0-6}$	$<1 \times 10^{0-6}$
Distilled Temp (°C)	65 - 75°C	65 - 75°C	65 - 75°C
Voltage (V)	230 - 250V	230 - 250V	230 - 250V
Boiological Activity	Pyrogen Free	Pyrogen Free	Pyrogen Free
Dimensions in mm (W x D x H)	650 x 630 x 440mm	650 x 630 x 520mm	650 x 630 x 440mm
Heater	Quartz	Quartz	Quartz
Boiler	Borosilicate	Borosilicate	Borosilicate
Condenser	Borosilicate	Borosilicate	Borosilicate

**NOTE:** The instrument will work with 100% efficiency at ideal condition only i.e. it will provide same output with given input and zero error.

Ideal Conditions :

1. Input Voltage 230 Volts
2. Ambient temperature of cooling water 25°C to 30°C
3. Flow rate of cooling water 7 to 8 bar recommended

The collection of distilled water will vary by +/- 20% if above parameters changes.

### NOTE

**This unit is recommended to operate with Pre-Filter and Water Softener**



## **CAUTION**

**ALWAYS USE HOSE PIPE FOR RAW WATER FEED INLET TUBING.**

Always use proper protective equipment. (Clothing, gloves, etc.)

Always follow good hygiene practices.

Each individual is responsible for his / her own safety.

Always wear shatter proof eye protection.



## **SAFETY AND WARNING**

Important operating and maintenance instructions. Read the accompanying text carefully.



### **Potential electrical hazards**

Only qualified persons should perform procedures associated with this Symbol.

Equipment being maintained or serviced must be turned off to prevent possible injury.

Inadequate earthing at the installation facility can lead to hazardous electrical shocks. The manufacturer is not liable for any injury or death resulting from electrical hazards due to faulty earthing in the lab.



### **Potential heat hazards**

Only qualified persons should perform procedures associated with this Symbol.

Do not touch the DDU unit directly when the unit is in hot condition.

## SAFETY PRECAUTIONS


The following precautions should be taken when operating or working near the DDU series:

- Do not use the product if there is any electrical or mechanical damage.
- Repair should be performed only by qualified individuals.
- Do not use accessories which are not recommended by the manufacturer as it may affect the performance.
- Do not use the unit in hazardous atmosphere or with hazardous material for which the unit is not designed.
- Always use the unit on a level & stable surface for best performance and maximum safety.
- The instrument is designed to be used in the laboratory environment.
- Clean the unit with a damp cloth using a mild detergent only.
- Follow the instruction for cleaning of the glass parts which is given on the front panel.
- If liquid is spilled on the unit, first disconnect the unit from the external (mains) power supply and then clean the unit with damp cloth.




**Check glass parts for any breakage before installation.**


## UNBOXING OF THE PRODUCT



**Primary Glass part box**



**Secondary Glass part box**





**Unit box**

1. Place the carton box in the proper direction.
2. Check the exterior carton for any damages.
3. Unbox the carton box from the top. If there is any physical damage found on the product report to the dealer/delivery agent.
4. Remove the accessories and the unit from the box safely.
5. Compare the in box items with the packaging list. If any of these items are missing, contact Labquest's Customer Service Center.


**(Read Manual before installation on the lab bench.)**

## PRODUCT IDENTIFICATION DDU



- A. CONTROL PANEL
- B. MODE KEY
- C. UP KEY
- D. DOWN KEY
- E. PRIMARY HEATER
- F. SECONDARY HEATER
- G. SS BOILER CLAMPS
- H. COOLING WATER OUTLET
- I. COOLING WATER INLET
- J. BOILER FEED
- K. PRIMARY BOILER PROBE SENSOR
- L. SECONDARY BOILER PROBE SENSOR
- M. HEATER CONNECTION



- N. RAW WATER FEED INLET
- O. BOILER FEED OUTLET
- P. COOLING WATER FOR PRIMARY CONDENSER
- Q. PRIMARY CONDENSER
- R. SECONDARY CONDENSER




- S. POWER SWITCH
- T. BOILER FEED COCK
- U. PRIMARY BOILER
- V. SECONDARY BOILER
- W. BOILER DRAIN OUTLET
- X. BOILER DRAIN COCK
- Y. DISTILLED WATER OUTLET TO SECONDARY BOILER
- Z. DOUBLE DISTILLED WATER OUTLET



## PRODUCT INSTALLATION

- Place the unit on a stable surface near a grounded electrical outlet.
- The surface should be clean, free of dust and moisture.
- Ensure that there are no flammable substances present near the unit .
- Allow sufficient clearance on all sides of the unit for proper ventilation.
- With the power switch in the OFF position, plug the power cord into a grounded receptacle.
- Make sure that a minimum 1/2 feet gap is maintained between the wall and other instruments present in the lab as shown in the figure below.



## PRODUCT INSTALLATION




Fig 16.1 Primary boiler bracket assembly








Fig 16.2 Controller box



Slot for  
Secondary Condenser  
Inlet Tubing




2 nos. of N6 screws




2 nos. of N6 screws


Fig 16.3 Controller box screwing




**Fig 17.1 Boiler Installation**



**Fig 17.2 Heater Installation**



**Fig 17.3 Heater Connection**




**Fig 17.4 Condenser Installation**

## PRODUCT INSTALLATION & TUBING CONNECTION


1. Remove Controller box from the unit box.
2. Fix the Boiler base bracket on the base frame. (fig.16.1)
3. Take controller panel and take out silicone tube from bottom of the panel and insert in the bottom slot on the base frame.(fig.16.2)
4. Place the Controller box as shown in (fig.16.2)
5. Fix the panel with the provided screws with the base as shown in (fig.16.3)
6. Remove Glass Part Box. Check for any breakage before installation.
7. Fix the Boilers with SS Clamps with screws provided with the unit.
8. Insert Glass Probe tube with threaded connector inside the boiler with the wall touching at the end of the boiler.
9. Now insert heater in the boiler and fix the wire behind of the Control Panel. Ensure that the heater end should touch the end wall of the boiler.
10. Open the Heater connection Box and fix the heater wire properly.
11. Now take temp. probe from the box and put it inside the temp. probe glass tube and plug it to the panel shown in the image. (ref page no. 14)
12. Now finally place the Condensers above the boiler as shown in (fig.17.4)

## TUBING CONNECTION

- A. Connect the hose pipe to the tap with SS hose clip.
- B. Fix the boiler feed silicone tube to the boiler feed cock.
- C. Connect the Cooling Water Inlet to the Primary Condenser and Secondary Condenser (Inlet tube for Secondary Condenser will come from Control Panel through bottom of the Boiler Base Frame)
- D. Connect the boiler feed cock silicone tubing to the Primary Boiler.
- E. Now fix the Distilled water Silicone tube to the Secondary Boiler feed.
- F. Now connect the condenser cooling water outlet silicone tubing. Now fix the silicone tube to the secondary condenser water outlet for distilled water.
- G. Fix the Distilled water Silicone tube to the Secondary Condenser for distilled water outlet.



## DESCRIPTION OF DISPLAY



1. **Yellow LED**
  - This indicates the input set indication.
2. **Red LED**
  - This indicates the heater ON status.
3. **Mode Key**
  - This is used to select the parameters.
4. **Up Key**
  - This is used for changing the values and scrolling in setting menu.
5. **Down Key**
  - This is used for changing the values and scrolling in setting menu.

## PROCESS / WORKING OF DDU




Fig 21.1 User Input Screen

1. The DDU interface consists of 3 keys MODE, UP, DOWN and a 4 digit seven segment display.
2. When the unit is turned ON the first screen is the user input screen.
3. Here users can put the amount of distilled water required by selecting or setting the amount by using the UP and DOWN keys.
4. The user can set the amount of water in Liters, the minimum amount of water that can be set by the user is 0.5 Liters i.e. 500ml




Fig 21.2 In Process Screen 1

5. Single press the MODE key to start the process after setting the amount of distilled water required.
6. After the start of the process the display will show the remaining output water quantity in liters.

The red LED on the right side of the display indicates the start of process.

7. See if the *SFIL* (Secondary boiler fill) in the settings menu is set to *YES*, after the start of the process the Primary Boiler heater will be ON. The display will show *bOL l*, which indicates that the Secondary Boiler fill is under process. Once the Secondary Boiler is filled the Secondary Boiler heater will be turned ON and the remaining time will be displayed.
8. The input water flow to the boiler can be controlled using the valve on the base of the unit behind the Primary Boiler. The user can increase or decrease the flow of water in the boiler according to the evaporation rate of the water in the boiler. This allows the user to save excess water that drains out when the boiler is overfilled.

### NOTE

- The SFIL (Secondary boiler fill) should set to "NO" once the Secondary Boiler is filled from the first cycle of process.
- If the Secondary Boiler is empty user should change SFIL (Secondary boiler fill) to "YES" to start the new cycle.






Fig 22.1

9. The user has to increase the pressure of the water.  
7 - 8 bar recommended

10. There is a temperature sensor feedback from the boiler which allows the unit to check there is enough water in the boiler. If the water level is low it will give an error of the boiler fill and the buzzer indication and heater will turn off. The error will be displayed on the display until there is user interruption by pressing the MODE key to stop the error indication and exit the process.
11. After completion of the time the process is stopped and the heater and the water flow in the condenser is turned off. The completion of process is indicated by the buzzer beep sound.
12. After the completion of the time the unit comes to the initial user input screen.
13. To terminate the process, long press the MODE key.



14. If user has set  $P_{on}$  greater than zero in settings, then the primary boiler will remain ON for that time period.
15. This is useful to refill the secondary boiler if required.
16. In secondary boiler refill process the display will show the above message on screen.
17. If  $P_{on}$  is settled to zero then after completion of process display will show the user input screen.

## SETTINGS OF DDU


To go in the setting menu long press the MODE key.

1. User Settings
2. Factory Settings

### USER SETTINGS


To go in the User setting menu long press the MODE key.

#### I. OUTPUT CALIBRATION



- Run the machine by setting the output value according to its variant i.e. for 1.5Ltr variant set the input value 1.5Ltr and run the process.
- Measure the output distilled water after completion of the process.
- Put the measured volume in the calibration setting and single press the mode key to save.

#### II. CLEANING CYCLE



- Single press the MODE key to go into the cleaning cycle. Follow the instructions displayed on the display.
- "b o i l e r C L E n" : Start of boiler cleaning process.


- “drAn oPEn” : Open the boiler drain valve. Press SET button after done.
- “drAn CLoS” : Close the boiler drain valve. Press SET button after done.
- “oPEn FEEd” : Put the boiler feed valve on MAX. Press SET button after done.
- “Add ACId” : Add 1 Ltr solution of sulphamic acid in the boiler. Press SET button after done.

**NOTE 1:** 2 cycles of boiler fill and drain will be performed for boiler rinsing after Acid solution drains.

- “FiLL” : Boiler will start filling.
- “HEAT” : Boiler will start heating.
- “rSt FEEd” : Put the boiler feed knob to the correct position. Press SET button after done.
- “Cond CLEn” : Cleaning of condenser will be done. 5 to 10 min of normal distillation operation will be performed.

**NOTE 2:** Do not use the distilled water collected during the Cond CLEn cycle.

### III. SECONDARY BOILER FILL ENABLE DISABLE




- Single press the MODE key to go into this setting.
- In this setting users can enable or disable the use of Secondary boiler fill.
- After entering into this setting users have to select between YES or NO.

- By using the UP/DOWN key, users can change the option  $\checkmark$  or  $\square$ .  
 $\checkmark$  - Secondary boiler fill is enabled.  $\square$  - Secondary boiler fill is disabled.
- Single press the MODE key after setting  $\checkmark$  or  $\square$  to save.
- When this is enabled then after start of the process the machine will fill the secondary boiler first and then the main process and the secondary boiler heater will be turned ON.

## FACTORY SETTINGS


To go in the User setting menu long press the MODE key.

### I. TEMPERATURE PROBE PRIMARY ERROR SET




- Single press the MODE key to go into this setting.
- The display will display the current temperature.
- Compare the temperature with the master temperature sensor/device and set the error if any.
- To set the temperature error single press the MODE key the display will show the error set value, use the UP/DOWN key to set the error value eg. If the current temperature is 24°C and the master temperature is 25°C then users have to add 1°C error so just set the error to 1°C.
- After entering the value using UP/ DOWN keys press the MODE key once to save the value.

## II. TEMPERATURE PROBE SECONDARY ERROR SET




- Single press the MODE key to go into this setting.
- The display will display the current temperature.
- Compare the temperature with the master temperature sensor/device and set the error if any.

## III. SAFETY TEMPERATURE SET




- Single press the MODE key to go into this setting.
- This is the maximum temperature that has to be present inside the boiler during the process. This is the factory setting.
- Use the UP/DOWN key to change the value, the maximum value that can be setted is 110°C.
- The minimum temperature value recommended to be setted is 104°C.

#### IV. OPERATIONAL TIME SET




- Single press the MODE key to go into this setting.
- This is the maximum process time.
- There are 4 operational time settings 06hr, 08hr, 10hr, 12hr.
- Users can use UP/ DOWN keys to scroll through the operational time setting. It is factory set to 6hr.
- Press the MODE key to set the maximum operational time.

#### V. MACHINE TYPE / VARIANT SELECT




- Single press the MODE key to go into this setting.
- This is used to set the machine type i.e 1.5L/hr, 2.5L/hr, 4L/hr.
- Users can use UP/ DOWN keys to scroll through the type setting.
- This setting is factory setted. Users should not change this setting.

## VI. FLOW SWITCH / SENSOR OVERRIDE



- Single press the MODE key to go into this setting.
- In this setting users can enable or disable the use of flow switch/sensor.
- After entering into this setting users have to select between YES or NO.
- By using the UP/ DOWN key, users can change the option YES or NO.  
YES - Sensor use is enabled. NO - Sensor use is disabled.
- Single press the MODE key after setting YES or NO to save.


## VII. SOLENOID VALVE ENABLE DISABLE



- Single press the MODE key to go into this setting.
- In this setting users can enable or disable the use of Solenoid Valve.
- This setting has to be used in case of solenoid valve failure.
- After entering into this setting users have to select between YES or NO.
- By using the UP/DOWN key, users can change the option YES or NO.  
YES - Solenoid valve is enabled. NO - Solenoid valve is disabled.
- Single press the MODE key after setting YES or NO to save.


- When the solenoid valve is disabled the machine will give a reminder or ask the user to close the tap after completion of the process with the display and buzzer indication.

## VIII. SECONDARY BOILER BALANCING



- Single press the MODE key to go into this setting.
- This is used to change/adjust the secondary boiler duty cycle of ON/ OFF time i.e secondary boiler power.
- The user can change the duty cycle from 75 - 95.
- The default and recommended duty cycle for best performance is 80.

## IX. SECONDARY BOILER REFILL



- Single press the MODE key to go into this setting.
- This is used to set the primary boiler ON time after completion of the process to refill the secondary boiler.
- The user can change the time from 0-20 mins.
- The default and recommended time is 0 min.

## ERRORS

Errors	Description	Troubleshooting
"Prb 1, Prb 2"	Temperature Probe Error	Please check if the probe is connected to the connector on the backside of the body. If error comes during the process check if probe is inserted properly in the glass tube inside the boiler.
"FLER"	Low Flow Error	Turn on the water flow tap and increase the flow of the water.
"boil FILL"	Boiler Empty Error	Check fill the boiler water level, the water level should be above the heater. Please check if the boiler feed valve is open.

## TROUBLESHOOTING

Sr. No.	Errors / Issues	Possibilities	Troubleshooting
1	Probe Error "P_r E 1" "P_r E 2"	1. Primary / Secondary Temperature Probe is not connected	1. Check temp. probe is connected properly to the din connector behind the Control Panel
		2. Primary / Secondary Temperature probe is faulty.	2. Replace the temp. probe with new temperature probe
		3. If an error occurs while a process is running	3. Check if heater is working, if not then connect the Heater wires properly to the heater terminal behind the Control Panel. i] Check the temperature probe is kept inside the glass rod properly. ii] Check Primary and Secondary probe kept inside primary boiler and secondary boiler respectively. iii] Lower down the glass probe tube near the Heater and then check the temperature.
2	Primary Boiler Fill boil Fill	1. Heater running without water in the Primary Boiler	1. Check for Inlet water supply is on and has proper flow. i] Check if boiler feed valve is set properly.
		2. Error occurring even if there is water filled in boiler, due to temperature probe error	ii] Check if cooling water is circulating properly in condenser
		3. Probe sensing false temperature, due to probe faulty or PCB problem	2. Go to settings "P_r E 1" (Primary Temperature probe error set) check the temperature with the master probe and put the error. OR If master probe not available then put "-3" or "-4" as error and check if its working properly, if problem occurs again then set error to "-6".
			3. If probe is showing some random temp. change the probe with new one and check the temp, if problem is not solved then replace the PCB with new one.
3	Secondary Boiler Fill boil	1. Secondary Boiler running without water	1. Check for Inlet water supply from the Primary Condenser to Secondary Boiler is proper. i] Check if cooling water is circulating in Secondary Condenser properly.

		2. Error occurring even if there is water filled in boiler, due to temperature probe error	If cooling water is not circulating then it will drain the boiler as pressure is ceated in the Secondary Boiler.
		3. Probe sensing false temperature, due to probe faulty or PCB problem	2. Go to settings "P r E r" (Secondary Temperature probe error set) check the temperature with the master probe if possible and put the error. OR If master probe not available then put "-3" or "-4" as error and check if its working properly, if again problem occurs the increase the error to "-6".
			3. If probe is showing random temperature value change the probe with new one and check if problem not solved then replace the PCB with new one.
4	Flow Sensor Error FLER	1. Input water flow is not proper	1. Check for the input water flow pressure if it is low then increase the flow or if pressure is not high but the flow is OK for distillation process then override it from the settings menu.
		2. Faulty Flow switch	2. Check if flow switch is working and the limit switch is pressed when the water is flowing through it. i) Check if the wires are connected to limit switch.
5	Heater not working	1. Due to improper connection to the connector on the back panel	1. Check if the heater connection is made properly to the terminal connector.
		2. Heater Failure	2. Remove the heater from the connector and put it directly to the 230V supply and check if the heater is in working condition, if no then replace the heater.
		3. PLA relay failure	i) Check for 230V with multimeter on the heater connectors place on the back panel of the control box when process is ON. ii) If not then check if 230V is coming on the PLA relay connector inside the control box. iii) If supply is not coming to 230V change the PLA relay and check again. If not supply is not coming to 230V after changing the relay, then replace the PCB.

## TROUBLESHOOTING

### 1. The unit is not turning ON.

- Check the power supply in AC mains.
- Make sure the power cable is inserted to the socket properly.
- Check whether the main switch is ON or OFF.
- Check if the illuminated switch is OFF.
- Ensure the main switch is ON.

### 2. If the flow error is displayed.

- Check the water flow.
- If the water flow is adequate to the unit and still it is showing the flow error fix the lateral cock provided for the condenser water drain.
- Turn down the flow of the Condenser Drain to reset the flow error.



## WARRANTY REGISTRATION

Please handover this Registration form to the distributor from where you have purchased this product.

The warranty is valid only when this warranty registration card is received by us within 30 days from the date of purchase.

Product: DDU 150  250  400

Product Sr. No.: \_\_\_\_\_

Date of Invoice : \_\_\_\_\_

Invoice No.: \_\_\_\_\_

### Customer name & address

Name : \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Telephone: \_\_\_\_\_

E-mail: \_\_\_\_\_

### Customer sign & seal

### Dealer name & address

Name : \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Telephone: \_\_\_\_\_

E-mail: \_\_\_\_\_

### Dealer sign & seal



# BOROSIL® Scientific

STATEMENT OF WARRANTY

Borosil confirms that this product has been manufactured in accordance with our technical specifications and quality requirements.

- Borosil warrants the product from manufacturing and workmanship defects for a period of 12 months from the date of invoice.
- Warranty void if apparatus is not operated as prescribed in Distillation Unit operating manual.
- To be covered under warranty.
  - Units have to be connected to standard 230V 50Hz, 15A wall sockets with proper earthing for DDU units.
  - The units should never be run with wet or dripping glassware.
  - Glass & Quartz being Fragile in Nature - **NO WARRANTY** for Glass Parts and Quartz Heaters is applicable.
  - Warranty does not cover rust and physical damage to metal parts due to corrosive environment in the lab.

**Terms:**

- In the event of malfunction due to defect, the buyer will have to follow the Borosil’s service process.
- Certain units can not be serviced/rectified at the buyer’s place and the units may have to be brought to Borosil’s service center as advised by Borosil’s representatives.
- In no event shall Borosil be liable for consequential or incidental damages.

<b>INVOICE DATE</b>	<b>BUYER</b>	<b>AFFIX SERIAL NUMBER</b>
<b>INVOICE#</b>		
<b>Dealer name &amp; address</b>		<b>Dealer sign &amp; seal</b>

**BOROSIL SCIENTIFIC LIMITED**

Corporate Office : 1101, Crescenzo G-Block, Opp. MCA Club, Bandra Kurla Complex, Bandra (E), Mumbai-400051, India.



**: MANUFACTURED BY :**

**Borosil Scientific Limited**

Plot No.7, Sr. No. 234, 235 & 245,  
Indialand Global Industrial Park,  
Hinjewadi Phase 1, Pune - 411057

*Write to us on above address.*

**: MARKETED BY :**

**Borosil Scientific Limited**

1101, G-Block, Parinee Crescenzo,  
BKC, Bandra East, Mumbai - 51

Maharashtra, India

**: CUSTOMER CARE CONTACT :**

**Phone : 1800 22 4551 | Email : [lab.support@borosil.com](mailto:lab.support@borosil.com)**

**Website : [www.borosilscientific.com](http://www.borosilscientific.com)**